

FASHION


OEKO-TEX®
CONFIDENCE IN TEXTILES
STANDARD 100 

CARBON= Class 1

 PU	 2-6.7 mil	 45° Blade	 MEDIUM pressure	 300-320°F	 15-20s	 PEEL: COLD
---	--	---	---	---	---	---

CARRIER: Adhesive & Transparent Polyester

APPLIES ON

-  Cotton
-  Polyester
-  Acrylic & Similar Fabrics

CARE

- Always respect the garment's instructions
- Allow 24 hours after application before washing
- Iron the backside only

WASH

- Max 140°F
- Preferably inside out
- Do NOT bleach
- Tumble-dry
- Okay to Dry-clean

STORE

- Up to 1 year
- In a dry room (60-85°F)
- Away from sunlight
- In vertical position

APPLICATION

1. Cut the material in reverse with the recommended blade
2. Weed the excess material
3. Heat press on the garment at 300-320°F & Protect the polyester carrier with silicone paper 15 - 20 sec - medium pressure
4. Peel the carrier off when cold

 **Chemica US**
Transfer your imagination

NOTE: For best results, we recommend performing a TEST prior to starting standard production