



APPLICATION:

- Perform test cut, adjust blade force and cutting speed as necessary. Use a 45 or 60 degree blade
- Cut MIRROR image through adhesive layer.
- Weed the excess material.
- Preheat garment 2 to 3 seconds.
- With MEDIUM pressure, press the image on the garment with its backing at 305°F (150°C) for 15 seconds.
- Peel the carrier off: WARM

WASHING INSTRUCTIONS:

- Wait 24 hours before first wash
- Machine wash warm or cold
- Use mild detergent
- Do not bleach or dry clean
- Dry on normal setting
- Wash regularly or inside-out Testing:
- Always test on a fabric swatch prior to production, especially on heavily treated fabrics.